

## **Error Code 200**

Manual Version 1.1 | Revised 1/8/24


## **Troubleshooting steps**

1 Check that the daisy chain position on the FuelCloud website matches the indicator on the CloudBox.

If the CloudLink does not have an indicator the daisy chain position is "0".



**2** Check that the D9 power LED on the CloudBox is illuminated.




3 Check that the AC/DC switch is set to the correct power type.






4 Check that there is the correct voltage on Pump Control 1.




**5** Check that the fuse next to the AC/DC switch is not blown.




**(i)** 

**Note:** The fuse is a 5mm x 20mm 1 amp 250V fast blow fuse.

**6** Check that the wiring between the CloudBox and CloudLink matches A to A, B to B, and GND to GND.





7 Check that the RS485 wire is the correct twisted pair + 1 and shield. FuelCloud recommends the Belden 8106A:

## Belden 8106A



8 If all of these are true, please contact FuelCloud support.



844-792-6071



support@fuelcloud.com