



# Wi-Fi Access Point Installation Guide

Manual Version 1.0 | Revised 09/11/24

## Included Parts

Ethernet cables not included.



**Access Point**



**PoE Injector  
(Power over Ethernet)**

## Instructions

Follow the steps below and refer to the diagram on page 2:

- 1** Power off the CloudBox.
- 2** Connect an ethernet cable between the CloudBox and the LAN port on the PoE injector. (For CloudBox 2, connect the ethernet cable to Ethernet Port 2)
- 3** Connect another ethernet cable between the PoE injector and the Access Point.
- 4** Connect the 120VAC power to the PoE injector
- 5** Power on the CloudBox.

# Diagram

