


## iPad Direct Connect (Lightning to Ethernet PoE)


Manual Version 1.0 | Revised 04/15/24

## **Instructions**


1 Plug the PoE injector into the outlet.



**2** Connect an ethernet cable from the PoE injector to the ethernet adapter.



**3** Connect the micro USB to Lightning cable from the ethernet adapter to the iPad.



**4** Connect an ethernet cable from the PoE injector to the CloudBox or to a router/switch.

